

Bicotest Model T631 TDR

HIGH SPECIFICATION CABLE FAULT LOCATOR

FEATURES/KEY BENEFITS

- High resolution, hand-portable cable-test tool for cable television and telecoms industries. At 3 metres it combines the shortest distance with a highly practical 12 kilometre long range.
- Automatic fault-finding is a simple touch-button operation enhanced by high resolution display. Faults and high reflective features are evaluated by a Return Loss Measurement function.
- This also provides a useful test method for contractors to demonstrate that connectors, taps and other cable work meets the required standards.
- A total of thirteen operating ranges with zoom facility includes very short pulse widths to identify cable features that are close together or nearby. These can be measured using the twin cursors.
- Genuine 2ns sine-squared pulse gives precision fault resolution.
- Pulse widths can be selected automatically for ease of fault location, or may be selected manually for uniform Return Loss Measurement.
- PC compatibility ensures waveforms can be analysed, stored and re-loaded for on-site, dynamic comparison of the waveforms when testing coaxial, CATV, CCTV and data cable systems.
- Dedicated function keys, help menu and clear display make the T631 easy to use.
- Dedicated mains blocking filter accessory gives high resolution fault location on LV mains cables.



PRODUCT SPECIFICATIONS	
RANGES:	0-3 m to 0-12 kms full screen, in 13 ranges (zoom of x2, x4, or x8 around cursor, depending on range)
ACCURACY:	Typically < 0.5%
RESOLUTION:	± 0.05% of range at 12 kms
PROPAGATION VELOCITY:	
PVF:	Variable 0.300 to 0.999
V:	90 to 300 m/μs
V/2:	45 to 150 m/μs
GAIN:	0-60 dB max, selectable in 6 dB steps Maximum sensitivity 15 mV = full scale
PULSE CHARACTERISTICS:	
Amplitude:	2.5 V into selected impedance
Width:	2, 10, 30, 100, 300 or 1200 ns, user selectable
Output Impedance:	50, 75 or 93 Ohms, user selectable
Noise Reduction Filter:	16 MHz Low pass
OUTPUT:	
Sockets:	BNC (Female)
Protection:	250 V rms, 0-60 Hz
DISPLAY:	
Type:	High resolution LCD with backlighting (switchable)
Cursor:	Two active cursors with individual control
MODES:	Direct Direct and Memory Differential Direct and Memory Memory
MEMORY:	15 locations that retain information until overwritten
INTERFACE:	RS 232C to printer or PC
POWER:	Internal NiMH Batteries - 8 hours operation (Auto Power-Off 5 mins after last key operation) Ext AC Adaptor, 120 V or 230 V available Ext DC, 12 V to 20 V operating; 15 V to 20 V charging
ENVIRONMENTAL:	
Operating Temperature:	-5°C to +50°C (23°F to 120°F)
Storage:	-20°C to +65°C (-4°F to 149°F)
Humidity:	93% at +40°C (104°F)
WATER INGRESS:	IP54
SAFETY:	IEC 1010
SIZE (mm):	75 x 183 x 300mm inc handle
WEIGHT (kg):	2.5kg inc battery
DELIVERY INCLUDES:	Weatherproof Shoulder Bag, 8 rechargeable NiMH cells, 1 x 3 m Test Lead, BNC to Crocodile Clips, AC Adaptor, DC Plug, Operating Manual
ORDERING DETAILS:	
T631 Option A:	230 V ± 10%, UK Plug
T631 Option B:	120 V ± 10%, USA Plug
T631 Option C:	230 V ± 10%, Euro Plug
OPTIONAL ACCESSORIES:	
X600 TRACEability	X600 is compliant with the 32 & 64 bit versions of Windows®XP, Windows Vista®, Windows®7 and Windows®8
T631F	AC Blocking Filter for use on live AC power cables
WARRANTY:	1 year

- Purpose designed for CATV, CCTV and coaxial cable
- 15 memories for on-site waveform comparison and storage
- Suitable for any type of metallic cable, including live AC in conjunction with a T631F blocking filter
- Genuine 2ns sine-squared pulse and short pulse widths give high performance fault location
- Single touch-button automatic fault location or feature measurement
- All faults clearly identified – from open circuits to wet joints
- Return Loss Measurement for fault analysis
- Use of T631F mains blocking filter gives safe, high resolution, fault location on LV mains networks.
- Full PC compatibility for in-depth fault analysis
- Measures metres, feet or time
- Easy to operate
- Large, clear waveform display of full trace for accurate diagnosis

Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.



Radiodetection (USA) 28 Tower Road, Raymond, Maine 04071, USA
Tel: +1 (207) 655 8525 Toll Free: +1 (877) 247 3797 Fax: +1 (207) 655 8535 rd.sales.us@spx.com www.radiodetection.com

Radiodetection Ltd. (UK) Western Drive, Bristol BS14 0AF, UK
Tel: +44 (0) 117 976 7776 Fax: +44 (0) 117 976 7775 rd.sales.uk@spx.com www.radiodetection.com

© 2014 Radiodetection Ltd. All rights reserved. Radiodetection is a subsidiary of SPX Corporation. SPX, the green ">" and "X" are trademarks of SPX Corporation, Inc. Radiodetection and Bicotest are trademarks of Radiodetection Ltd. Due to a policy of continued development, we reserve the right to alter or amend any published specification without notice. This document may not be copied, reproduced, transmitted, modified or used, in whole or in part, without the prior written consent of Radiodetection Ltd.